FF10BKW

Category: تقنية

written by Mahdi MILED | 20 نوفمبر، 2024

embraco	FF10BK	LBP/MBP/HBP	115 V	Blend

Wiring Diagram



Compressor Terminals

C = Common
R = Run
S = Start

Electrical components are supplied unassembled. Use of components other than specified will void warranty.

Tube Diameter

ID	Inch	MM
process	.255	6.5
suction	.325	8.3
discharge	.255	6.5

Dimensions (inches)

A:7.93" B: 6.8" C: 8.02" D: 4.0" E: 6.5"



Compressor, Embraco, FF10BKw, hbp, lbp, 1/4 hp++, r12 , Start capacitor 460-552 mfd,